



CEME-TUBE LLC.
2907 Harvey St.
Hudson, WI 54016
Tel: 715-377-2133
Fax: 715-377-2135
Email: info@cemetube.com
www.cemetube.com

Installation Guide for 18", 24" and 30" Light Pole Ceme-Tube.

Note: The Light Pole **Ceme-Tube** is a finished product, please store Light Pole **Ceme-Tube** on end and protect them from unnecessary damage.

- Determine the exposed above grade height of the Light Pole **Ceme-Tube**.
- Slide the collar end of the Light Pole **Ceme-Tube** onto the non-collar end of the black Standard **Ceme-Tube**. (If black Standard **Ceme-Tube** is not being used, skip to step 4.)
- Fasten together with any type of screws in dimpled location of collar. (4 screws per connection)
- Place entire assembly into hole. Note: To obtain proper height, either attach stilts to bottom tube to rest on bottom of hole, or attach a wooden frame around the Light Pole **Ceme-Tube** to hang into hole. Attach wooden support frame below the level of final grade to avoid exposed screw holes in the finished Light Pole **Ceme-Tube**.
- If backfilling, do so evenly and/or brace as necessary.
- Fill with concrete at your convenience.
- If necessary, clean concrete residue off exterior of Light Pole **Ceme-Tube** with water.
- Installation is complete.

